



STAMP 1600.1D

RMS Power: 1CH x1600w@1ohm

RMS Power: 1CH x800w@2ohm

RMS Power: 1CH x400w@4ohm

Max Power: 1600W Max

LPF: 90Hz-10kHz

HPF:10Hz-90Hz

Frequency response range: 20-10kHz

Bassboost: 0-10dB

Bassboost frequency: 35-55Hz

S/N: 92dB

Clip/Power/Protect indicator

With remote gain controller

Size: 222x216x72MM



STAMP 500.1D

STAMP 1200.1D

STAMP 1600.1D

Full Range Class D Car Amplifier

STAMP 1200.1D

RMS Power: 1CH x1200w@1ohm

RMS Power: 1CH x600w@2ohm

RMS Power: 1CH x300w@4ohm

Max Power: 1200W Max

LPF: 90Hz-10kHz

HPF:10Hz-90Hz

Frequency response range: 20-10kHz

Bassboost: 0-10dB

Bassboost frequency: 35-55Hz

S/N: 92dB

Clip/Power/Protect indicator

With remote gain controller

Size: 185x216x72MM


Notes on the power supply

POWER CONNECTION LEADS

- Connect the 14.4V power supply lead only after all the other leads have been connected.
- Be sure to connect the ground lead of unit securely to a metal point of the car. A loose connection may cause a malfunction of the amplifier.
- Be sure to connect the remote control lead of the heat unit to the amplifier's remote terminal. A loose connection may cause a malfunction of the amplifier.
- When using a car audio without a remote output on the amplifier, connect the remote terminal to the accessory power supply.
- Use the power supply lead with a fuse attached
- Place the fuse in the power supply lead as close as possible to the car battery.
- Make sure that the leads to be connected to the 14.4V and GND terminal of this unit are larger than 10-gauge (AWG #10) power cables.


Front panel connection

STAMP 500.1D
STAMP 1200.1D
STAMP 1600.1D




Power connection leads

STAMP 500.1D STAMP 1200.1D



STAMP 1600.1D



STATUS

AUDIO

STAMP 500.1D

RMS Power: 1CH x500w@1ohm

RMS Power: 1CH x300w@2ohm

RMS Power: 1CH x170w@4ohm

Max Power: 500W Max

LPF: 90Hz-10kHz

HPF:10Hz-90Hz

Frequency response range: 20-10kHz

Bassboost: 0-10dB

Bassboost frequency: 35-55Hz

S/N: 92dB

Clip/Power/Protect indicator

With remote gain controller

Size: 145x216x72MM

Trouble shooting II

| Symptom | possible cause | actions to take |
|-------------------------------|--|--|
| distorted output | speakers are blown | check system with known working speakers and repair or replace as needed |
| Poor bass response | speakers wired wrong polarity causing cancellation at low frequencies | check speaker polarity and repair as needed |
| | crossover set incorrectly | reset crossover referring to the multi-cross crossover configuration sections of this manual for detailed instructions |
| battery fuse blowing | impedance load to amplifier too low | check impedance load if below 2Ω stereo or 4Ω mono rewire speakers to achieve a higher impedance |
| | short in power wire or incorrect power connections | check power and ground connections and repair as needed |
| | fuse used is smaller than recommended | replace with proper fuse size |
| | too much current being drawn if below 2Ω stereo or 4Ω mono rewire speakers to achieve a higher impedance | check speaker impedance load, |
| | short in power wire or incorrect | check power and ground connections as repair as needed |
| amplifier fuse blowing | too much current being drawn | check speaker impedance load, if below 2Ω stereo or 4Ω mono rewire speakers to achieve a higher impedance and replace with recommended fuse size |
| | | check power and ground connections and repair as needed |
| | fuse used is smaller than recommended | replace with proper fuse size |

Trouble shooting I

| Symptom | possible cause | action to take |
|--------------------------------|--|---|
| no output | low or no remote turn-on input | check remote turn-on voltage output at amplifier and correct as needed |
| | fuse blown | check power wire integrity and reversed polarity, repair as needed and replace fuse |
| | power wires not connected | check power wire and ground connections and repair or replace as needed |
| audio cycles on and off | audio input not connected or no out put from source | check input connections and signal integrity, repair or replace as needed |
| | speaker wires not connected | check speaker wires and repair or replace as needed |
| | speakers are brown | check system with known working speaker and repair or replace speakers as needed |
| | thermal protections engages when amplifier heat sink temperature exceeds 90 °C | make sure there is proper ventilation for amplifier and improve ventilation as needed |
| | loose or poor audio input | check input connections and repair or replace as needed |
| distorted output | amplifier level sensitivities set too high; exceeding maximum output capability of amplifier | reset gain referring to the turning section of manual for detailed instructions |
| | impedance load to amplifier too low | check speaker impedance load if below 2Ω stereo or 4Ω mono rewire speakers to achieve a higher impedance |
| | shorted speaker wires | check speaker wire connection and repair or replace as needed |
| | speaker not connected to amplifier properly | check speaker wiring and repair or replace as needed refer to the installation section of this manual for detailed instructions |